



Stand on the passenger side of the vehicle look straight down into the engine. Both harnesses are accessible if you can reach between the air intake and the intake horn.