

OBD Details

1. Plug Autocal/V2 into truck and laptop, turn key to run.
2. Open EFILive Scan and Tune V8
3. Click F4: OBD
4. Click Autodetect
5. Once that finishes click read
6. Once the field on the right populates right click and select copy all, paste that into a email or the order form, it will have all the numbers we need.