

Using Switch on the Fly (Cruise Control Method)

Step 1: Meet switching requirements

- Vehicle must be equipped with OEM cruise control hardware and steering wheel.
- Vehicle must be On or Running, and Cruise Control must be deactivated.

Step 2: Activate the Switching Menu



**Once activated, or when a slot is changed, map switching is available for 10 seconds.*

Step 3: Now that we are activated.



Active Slot will be limited to the Max Allowed Slots calibration setting.

Step 4: Deactivate the Switching Menu

The switching menu will automatically deactivate after 10 seconds if no buttons are pressed.

