

HP TUNERS

***WITH AISIN TRANS TUNING YOU WILL NEED TO DO THE ECM AND TCM STOCK READ SEPERATELY!

Make sure you are on the latest beta version of VCM editor.

(To confirm click on help and then about.)

Download VCM suite beta from here

https://www.hptuners.com/downloads/?gad_source=1&gclid=CjwKCAjwtdi_BhACEiwA97y8BNYK1-TVNXRWbzxMreBFPfvCaT5zVbkR4sAJj5kBMVmNqb9QuVdIIhoCoOAQAvD_BwE

How to read the truck:

<https://support.hptuners.com/support/solutions/articles/153000064356-how-to-read-license-and-flash-an-ecm>

How to do a info log:

<https://support.hptuners.com/support/solutions/articles/153000064334-how-to-generate-a-vcm-suite-infolog>

When you are done, send over the info log and stock read.

Once you have the tune file back can flash it in. ******MAKE SURE YOU ARE USING A BATTERY CHARGER******

To apply the credits, click on help then resync interface